

TRADESMAN FILLER

READY TO USE MULTI-PURPOSE FILLER

19 August 2015

YOUR SMART ADVANTAGES

- Interior and exterior
- Easy sanding
- Easily nailed or screwed without cracking
- Low odour
- Paintable
- Minimal shrinkage

USES

 Filling holes and cracks in timber, concrete, plaster and stone

PRODUCT CHARACTERISTICS*	
Colour	Off white
Dry time	60 – 90 minutes for 1mm film on timber at 25°C. Thicker layers and cold conditions will require longer
Product code 350g tub/9 per carton 750g tub/6 per carton	30606141 30606142

DIRECTIONS FOR USE

Read and understand the Material Safety Data Sheets before using this product.

SURFACE PREPARATION

Ensure all surfaces are clean, dry and free from dust and grease. Remove all loose materials (including old filler) from the areas to be filled.

APPLICATION

- Using a putty knife or spatula press Bostik Tradesman Filler into the cracks or holes to be filled.
- For deep holes and cracks apply Bostik Tradesman filler in layers of no more than 6mm. Allow each layer to dry before applying the next layer.
- Once the filler is dry, sand smooth and paint using water or solvent based paint. Priming is recommended – follow the paint manufacturer's recommendation.

 If the product in the tub becomes too stiff from drying on exposure, add a small amount of water, a bit at a time, mixing between additions to bring it to a usable consistency. The addition of too much water will result in shrinkage when applied.

LIMITATIONS

- This product has limited flexibility, use a flexible filler such as Bostik Fill A Gap for low movement joints or Bostik Safe Seal for high movement joints.
- Bostik Tradesman Filler should not be used in conditions where it will be continuously wet.
- Bostik Tradesman Filler performs best in exterior conditions when it is painted.

CLEANING

Water while wet, mineral turps when dry.

STORAGE AND SHELF LIFE

Store in a cool dry place below 25°C and out of direct sunlight. Protect from frost or freezing. The product is best used 1 year from the date of manufacture when stored as directed.

DISPOSAL

Empty containers may be disposed via local landfill. If spilt, absorb with clay, sand or earth. Collect and seal in properly labelled metal container. Dispose of according to local authority regulations. Do not dispose of down drains or into local waterways.

Bostik New Zealand Ltd, 19 Eastern Hutt Rd, Wingate, 5019 Lower Hutt, New Zealand. Tel: +64 4 567 5119 www.bostik.co.nz

TRADESMAN FILLER

PRECAUTIONS IN USE

Complete details on each of the products mentioned are available on the product Safety Data Sheets. To ensure no harm is caused to persons using Bostik products, it is recommended that all concerned read the appropriate Safety Data Sheets. Visit www.bostik.co.nz for copies.

FIRST AID

Call a POISON CENTER or doctor/physician if you feel unwell.

IF ON SKIN: Wash with plenty of soap and water. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

IF SWALLOWED: Immediately call a POISON CENTER or doctor/physician

For emergency information contact the National Poisons Information Centre, phone 0800 764 766 (0800 POISON) or CHEMCALL, phone 0800 243 622.

BOSTIK HOTLINE

Smart help 0508 222 777

This datasheet is for the general help of users. It is provided in good faith. The data is current and accurate to the best of our knowledge. Differing materials, substrates, environments, site conditions, and product storage, handling and application may affect results. Users should carry out tests to decide the product's suitability for purpose. This data sheet and the properties of the product may change without notice. Users, suppliers and retailers should check that the data sheets they have are the latest. To the maximum extent permitted by law, Bostik disclaims all warranties in relation to manufacture and use of the product. Bostik is not liable for representations made by users, suppliers or retailers about the product. Bostik is not liable for any loss or damage resulting from incorrect, careless, or negligent use or storage of the product, including use of out of date product. Any liability arising from use of the product is limited to the replacement or purchase price of the product. Bostik is subject to the exclude rights and remedies that cannot be excluded by legislation, for example under the Consumer Guarantees Act 1993. Sale of the product by Bostik is subject to the Bostik New Zealand Limited Conditions and Terms of Sale. For more information on Bostik, products, and conditions of use and sale visit www.bostik.co.nz

Technical Advice

Tel: 0508 222 777

nzsales@bostik.com

Bostik New Zealand Ltd, 19 Eastern Hutt Rd, Wingate, 5019 Lower Hutt, New Zealand. Tel: +64 4 567 5119 www.bostik.co.nz