



Universal Cleaner

Powerful universal cleaner for use with Kärcher pressure washers. With new active dirt remover which effortlessly removes oil, grease and stubborn mineral-bearing dirt with just cold water. For use all around the house and garden and on vehicles.



Properties

- Active dirt remover for quick and efficient cleaning of oils, fats, residues containing minerals and soiling from emissions
- pH neutral
- The Plug 'n' Clean system is the easiest and quickest way to apply cleaning agent using a Kärcher pressure washer
- Tensides biodegradable in accordance with OECD
- Ready-to-use detergent (RTU)

Application areas

- Home and garden

Application

- High-pressure cleaner

Container sizes	VE*	Part number
1 l	6	6.295-753.0

*VE: packaging unit

Application:

High-pressure cleaner

- Connect the bottle to the pressure washer, put the suction hose in the bottle or pour the detergent into the tank. Dispense under low pressure, let it work in for a short while and then rinse thoroughly under high pressure.

Instructions for use:

- Shelf life: 4 years

Warnings and safety recommendations according to EC Directives:

- P102 Keep out of reach of children.
- Z 23 Data sheet available for professional users on request.

Environmental characteristics:



Surfactants based on 100% renewable raw materials



Bottle and label 100% recyclable



Highly efficient natural ingredients



Bottle made of 45% recycled material



Surfactants biodegradable (anaerobic – OECD 311)

Please contact us for more information:

Kärcher Limited

66 Allens Road
East Tamaki, Auckland 2013
New Zealand

T + 64 9 274 4603
F + 64 800 111 527
info@karcher.co.nz