



CRADLE UNIT

PART	DESCRIPTION
125-100	Complete Cradle Assembly
125-102	Pull Pin with Fasteners
125-103	Complete Cross Arm Assembly
125-105	Cross Arm Support Hooks Each
125-106	End Caps per Piece
125-107	Outrigger with End Cap
125-117	Complete Mounting Head Assembly
125-120	Cradle Body

WINCH UNIT

PART	DESCRIPTION
125-300	Complete Winch Assembly
125-305	Complete Brake Arm Assembly
125-307	Tension Spring "B"
125-308	Brake Handle Cover per Piece
125-310	Winch Handle

FRAME UNIT

PART	DESCRIPTION
125-200	Complete Frame Assembly with Winch & Standard "A" & "B" Sections
125-201	Frame Housing
125-202	Winch Post with Pin & Fasteners
125-205	Cable 13.5" 1/8" aircraft
125-206	Cable Sheave with Axle & Pins (3 Total)
125-207	Retaining Hook
125-208	4" 'A' Section (Inner)
125-209	4" 'B' Section with Sheaves
125-210	Winch Post End Cap

TRIPOD BASE UNIT

PART	DESCRIPTION
125-400	Complete Tripod Base Assembly
125-403	Backstop Tip Per Piece
125-406	Caster 5"
125-411	Center Leg