

TOOLS REQUIRED

Drill



Screwdriver



Pliers



Level



Tape Measure



Pencil



PRECAUTIONS

- We recommend a qualified person installs the mirror
- Install the mirror at a height above the basin where water will not splash on it. Approx. 200mm up from the basin. The mirror warranty is void if installed below 150mm from the basin top.
- Use secure wall fixings appropriate for you wall type
- We recommend two people to install heavy or large mirrors
- To avoid damage use a soft mat or rug for putting the mirror down on while installing
- Handle mirror with extreme care.
- Do not strike the mirror glass with hard or pointed objects
- Do not place hot or cold items against the glass.
- We recommend to hand screw fixings (power tools may break gib fixings or over-tighten)
- Keep you workspace clean & clear of obstacles

MAINTENANCE

- For a safe and excellent chemical cleaner option please contact us.
- Alternatively when cleaning the glass always use a damp cloth with no chemical cleaners. Many glass cleaners have chemicals (acid base) which will attack the silver mirror edges and voiding the warranty.
- Do no use a scouring pad.
- Please retain this for future reference

INSTRUCTIONS

STEP 1 Measure the distance between the centres of the two hangers. Record your measurement A: _____

On some large mirrors there will be additional hangers, in this instance record all the distances between each hanger.

STEP 2 Measure the distance from the top of the mirror to the top of the hanger. Record your measurement B: _____

STEP 3 Lightly pencil mark on the wall where you want the top of the mirror to be. Using Measurement B, measure down from this mark and draw a level line the width of the mirror. Use a spirit level to ensure the line is level. Mark the centre point for the width of the mirror. Clean your first top mark off the wall.


STEP 4 From the centre point measure in each direction half of measurement A and mark with a cross. Check the distance between these 2 crosses is equal to Measurement A.

STEP 5 Screw the L screw into place, leave approx. 5mm gap between the wall and the head of the screw. The head of the screw should point upwards.

If drilling into gib board (and no wooden stud in behind) insert the wall fixings or use another suitable hollow wall anchor in the exact centre of the mark on the wall.

STEP 6 On the wall (above the mirror) and on the top of the mirror, attach pieces of easy to peel masking tape (or post-it notes) in the position of the fixings. Use these as a guide when sliding the mirror onto the L Screws.



Using 2 people carefully lower the mirror onto the 2x L screws fixed to the wall.



Strap hangers are attached to the mirror



2 x L Screw wall hangers included



PLEASE READ CAREFULLY

THIS MIRROR CARRIES A FULL WARRANTY, PLEASE INSPECT THOROUGHLY BEFORE INSTALLATION TO ENSURE THIS UNIT HAS NOT BEEN DAMAGED IN TRANSIT AS THE WARRANTY DOES NOT COVER THE COST OF REMOVAL AND INSTALLATION ONCE INSTALLED.