

HI RISE VEGIE SPRAY MIXER INSTALLATION GUIDE

TECHNICAL SPECIFICATIONS

Operating Pressure:

Minimum 150 kPa, Maximum 1000 kPa.

Recommended 150-500 kPa.

Recommended installation of a pressure limiting valve if supply exceeds 500 kPa.

Operating Temperature:


Hot: Max 80°C.

Cold: Min 5°C.

NB: New Zealand Building Code Clause G12 - Water Supplies specifies all outlets used primarily for personal hygiene shall deliver water at a safe temperature.

Inlet Connections:

All 1/2" BSP.



Methven warrants this product against manufacturing defects and that it is suitable for use under the operating conditions specified in this instruction sheet.

For your warranty please refer to www.methven.com or call Customer Service

New Zealand
0800 804 222

Australia
1300 638 483

USA
1800 975 5409

UK
0800 195 1602



IMPORTANT

Please read all of the instructions before installation

This mixer is designed for mains pressure systems.

This mixer is not recommended for use in uncontrolled heating systems such as wet-backs or solar heating units.

All pipework must be thoroughly flushed prior to the installation of the mixer. Inline filters must be fitted on both hot and cold supplies to prevent foreign particles damaging the ceramic cartridge.

1. Cut a 40mm diameter hole through the bench top. Maximum bench thickness 30mm.
2. Pass base ring over flexible hoses. Pass hoses through bench & fix to base of mixer.
3. Pass rubber sealing washer & support ring over flexible hoses & secure to mixer using the clamp plate & rubber washers with large size brass nut.
4. Pass the outlet hose through the hose guide & secure using either the small nut (thinner bench material) or brass nut with washer.
5. Connect brass nut with washer (if not done previously) & outlet hose.
6. Fit lead weight to outlet hose using rubber strip and screws provided. Optimum position is at the bottom of the looped outlet hose.
7. Flush pipework thoroughly.
8. Connect the hoses to their respective water supplies (see over page). Two rubber washers are provided for the flexible hose supply connections. Machined nipple ends are required to ensure a seal to the flexible hose nuts and the rubber washers.
9. Connect the spray head to the outlet hose.

