

INSTALLATION INSTRUCTIONS



SHOWER | VALENCIA ELITE Alcove Pivot Shower



Note: Tapware and accessories not included.

BEFORE YOU BEGIN

Before installing the shower please read these instructions carefully to familiarise yourself with the required tools, materials and installation sequences. Please leave these instructions for the consumer after installation. Refer to the separate care and maintenance guide for important care and cleaning information.

Ensure that the shower tray and wall, if applicable, are completely finished prior to installing your shower door and return. Follow all warnings, cautions and instructions contained in this guide.



SAFETY

1. ENGLEFIELD strongly recommends that a minimum of TWO persons install this enclosure due to the weight of the door panels.
2. Toughened safety glass cannot be cut. Risk of injury or product damage.
3. Wear protective footwear when lifting panels.
4. Wear safety glasses when drilling.




ATTENTION


1. The wall retainers must be installed onto a waterproof, vertical and flat wall surface. Failure to do so will result in an unsatisfactory seal, which may cause property damage. The wall inclination (out of squareness) is recommended to be out by no more than **+/- 4mm/m**.
2. Please install this door onto an ENGLEFIELD Quick - Fit® shower tray only, unless installing directly onto tiled walls and floor.
3. Care must be taken when drilling into walls and floors to avoid any hidden pipes or wires.
4. It is the responsibility of the INSTALLER to ensure that the installation complies with council and or local authority by laws.

Instructions, drawings, and diagrams contained in this manual present information available at the time of printing. Although every attempt has been made to keep them up-to-date, Englefield reserves the right to implement product changes without further notice.

TOOLS AND MATERIALS REQUIRED



PARTS IDENTIFICATION




CONSTRUCTION REQUIREMENTS
Wall Framing


Due to the weight of the glass panels Englefield strongly recommends fixing the wall retainers to double studs for all installation types (as shown).

For acrylic tray with acrylic or tiled wall

Size	Dim 'A'	Dim 'B' ⁺² ₋₀
750 x 900	900	767
900 x 750	759	882
900 x 900	900	884
1000 x 1000	1000	984
1200 x 900	900	1184
1200 x 1000	1000	1184

NOTE: This setup allows for the use of standard 10mm wall board. A thicker wall board could make the recess too narrow for the door system.




For tile floor and tile wall - Finished surfaces

Size	Dim 'C'	Dim 'D' ⁺⁵ ₋₀
750	N/A	738
900	N/A	856
1000	N/A	956
1200	N/A	1156

Finished /tiled hob to be:

- 1) Minimum 70mm wide.
- 2) 1-2° fall front to back is acceptable.
- 3) Level (+/-0mm) left or right.



INSTALLATION - Options

OPTION 1 - Acrylic Wall & Tray

Tray: For tray installation refer to the instructions supplied with the tray.

Wall: For wall installation refer to the instructions supplied with the wall.

- Proceed to Door Installation.

OPTION 2 - Tiled Wall & Acrylic Tray

Tray: For tray installation please refer to the instructions supplied with the tray.

Tiled Wall:



ATTENTION

The complete door system **MUST** be installed onto the waterproof membrane **PRIOR TO WALL TILING**.

Failure to install the complete door system before tiling may mean the door system will not fit on the shower tray due to the tile thickness.

- Proceed to Door installation.


OPTION 3 - Tiled Wall & Floor

- The door and return can be installed directly onto the wall and floor tiles.


- Proceed to Door installation.

INSTALLATION

1



Caution: Ensure tray or tiled floor is level & walls are vertical & square.





Tip: Cover the waste to prevent the loss of small parts. If installing onto a tray protect the tray surface during installation.

(a) Mark the locations of the wall retainers.

For tray base option:

- Mark 10mm in from top edge of tray.
- (Mark 15mm in on 90mm sill height Quick-Fit Trays)






For tiled floor option:

- Mark from back wall to outer edge of both retainers with your preferred dimension 'A'.



(b) This shower is reversible. Please choose which side you would like the door to open from.




2

IMPORTANT! The handle side retainer must be fitted first.

- (a) Position a wall channel on the "handle side" wall. The flange with pre-drilled holes should face inside the enclosure. Using a level, make sure that the channel is upright.
- (b) Mark the position of fixing holes down the centre of the channel, then remove channel.
- (c) Drill with a 3mm bit. For other types of wall structure, alternative fixings may be required (not supplied).
- (d) Apply silicone sealant along the length of the wall and at the bottom where the wall channel will be placed, including the top of the tray.
- (e) Position the wall channel on the wall and install the fixing screws **(A)**
- (f) Fully tighten the fixing screws, making sure that the wall channel remains vertical.


3

- (a) Place the other wall channel on the opposing wall. Use a level to ensure that it is upright.
- (b) Mark fixing hole positions down the inner flange of the channel, then remove the wall channel.
- (c) Drill with a 3mm bit. For other types of wall structure, alternative fixings may be required (not supplied).
- (d) Apply silicone sealant along the length of the wall and at the bottom where the wall channel will be placed, including the top of the tray.



Note! The hinge side wall channel is not fitted at this stage.


- (e) Fit the free wall channel onto the hinge side of door assembly and hold in place.



4

- (a)** Slot the door assembly into the pre-installed (handle side) wall channel, and swing the entire door frame into position.


Note! Be careful not to scratch the extrusions or smudge the silicone sealant during this process.



- (b)** With the wall channel in position, insert the fixing screws **A** into the pre-drilled holes.
(c) Use a level to ensure the channel is kept upright, then fully tighten the fixing screws.
(d) Remove any excess silicone sealant from inside the shower enclosure.

5

- (a) Centralise the door frame within the wall channels, making sure that the door frame is square.




- (b) From the inside of the enclosure, drill four holes in the door frame through the centre marked points on the wall channel with a 3mm HSS drill (not supplied).

- (c) Install and tighten the wall channel assembly screws **B**.

- (d) Repeat the process for the other wall channel.


- (e) Fit the corner covers to the wall channels. They should 'snap' into place.




6^a





750 DOORS
900 DOORS
1000 DOORS
[for 1200 doors
see page 11]



Vertical Door Seal



Door Seal




Door Seal

- (a) Install the door seals and magnetic strip onto the door.
- (b) Install the door handle, ensuring that the grub screws are on the underside.


6^b



1200 DOORS
[for 750,900,1000
doors see page 10]




Vertical Seal





Door Seal

Magnetic Strip

Door Seal




- (a) Install the vertical seal onto the fixed panel.
- (b) Install the door seals and magnetic strip onto the door panel.
- (c) Install the door handle, ensuring that the grub screws are on the underside.



- (a) Fit the caps to the top of the extrusions. Add silicone or modify caps to fit if required.
- (b) Apply sealant along the outside surfaces of the enclosure. Do not seal from inside.
- (c) Install the wall finishing strips, if desired.
- (d) Allow the silicone sealant to cure for 24 hours before use.

Installation complete.

SPARE PARTS



** Colour code must be specified when ordering

CLEANING AND MAINTENANCE INSTRUCTIONS

Please refer to our website for cleaning instructions.

CONTACT AND WARRANTY INFORMATION

NEW ZEALAND

Kohler New Zealand Limited

0800 100 382

info@englefield.co.nz

englefield.co.nz

AUSTRALIA

englefield.com



INSTALLATION INSTRUCTIONS



SHOWER

QUICK-FIT® SHOWER TRAY

Low Profile Tray
70mm Sill height



BEFORE YOU BEGIN:



IMPORTANT

NOTE: Building requirements can vary, local regulations must be checked prior to installation.

NOTE: Drawings in this document are not to scale.

A) SHOWER TRAY & ENGLEFIELD DURACRYL WALL/TILED WALL INSTALLATION OPTIONS

The tray should be installed in accordance with one of the following recommended methods:


Fig. 1 - Wet Area Wall Board & Englefield Duracryl® Wall



IMPORTANT

Install Duracryl Shower Wall as per installation instructions supplied with the wall.

TH (Tray height):
Low Profile - 110mm



**IMPORTANT**

Wall retainer extrusions or door must be installed **prior to tiling**.
Please refer to installation instructions provided with shower door.

Fig. 2 - Wet Area Wall Board & Tiles - Method 1





Fig. 3 - Wet Area Wall Board & Tiles - Method 2



Please note: Instructions, drawings, and diagrams contained in this manual present information available at the time of printing. Although every attempt has been made to keep them up-to-date, Englefield reserves the right to implement product changes without further notice.

B) FLOOR CONSTRUCTION

TIMBER

When installed on a timber floor, the floor board should be supported at not greater than 500mm centres and the cut-out waste connection kept to a minimum.


CONCRETE

When installed on a concrete slab floor, chases or channels left for plumbing must be completely backfilled.

C) WALL CONSTRUCTION

- 1) Ensure that the wall framing and lining are constructed in accordance with one of the following illustrations (Fig. 4 or 5).
- 2) Measure the back and side wall(s). The dimensions of the shower area (measured to the finished surface of the wall board) must be as shown below. This is particularly important for Alcove (3-sided) installations where an Englefield Duracryl® wall will be installed.
- 3) Ensure studs are located as shown (dimensions A,B & C) to provide a solid support for the door and return panels.


Fig. 4 - Corner (2 sided) Wall



SHOWER TRAY	A	B
900 X 750 *	734	884
900 X 900	884	884
1000 X 1000	984	984
1200 X 900 *	884	1184
1200 X 1000 *	984	1184

* Asymmetric trays are handed, eg: 900x750 Right = 750x900 Left

Fig. 5 - Alcove (3 sided) Wall



SHOWER TRAY	C	D
900 X 750 X 900	885	747
750 X 900 X 750	739	864
900 X 900 X 900	884	864
1000 X 1000 X 1000	984	964
900 X 1200 X 900	884	1164
1000 X 1200 X 1000	984	1164

Note: Dimensions are to the finished surface of the wall board

INSTALLATION - SHOWER TRAY**A) CEMENT SLURRY**

Many tradesmen prefer to install trays on a weak cement slurry (approx. 10:1 sand and cement) thus ensuring complete support over the entire load-bearing area. However this step is not necessary providing that installation is on a flat, level surface free of bumps and protrusions. When installed on a concrete slab floor, chases or channels left for plumbing must be completely backfilled.


Building requirements can vary, local regulations must be checked prior to installation.

B) CONSTRUCTION ADHESIVE

1) With the tray laying upside down, apply a suitable adhesive, such as Sika Nailbond PB, to the bottom edges of all feet and the bottom edge along the front of the tray.



Note Sika® Showerbond is not recommended. Cartridges from ENGLEFIELD adhesive /sealant packs must not be used for this purpose.



2) Carefully turn tray over and place into position. Ensure that the tray is level.

3) Leave the tray in place, do not stand or walk on it for 24 hours to allow enough time for adhesive to cure.

INSTALLATION - SHOWER WASTE

Install shower waste. Follow instructions supplied with the waste

INSTALLATION - ENGLEFIELD DURACRYL® WALL

Install wall if applicable. Follow instructions supplied with the wall.

CONTACT AND WARRANTY INFORMATION**NEW ZEALAND**

Kohler New Zealand Limited

0800 100 382

info@englefield.co.nz

englefield.co.nz

AUSTRALIA

englefield.com




Englefield Corner PLUS Shower Walls

With the demands of everyday family life in mind, this beautifully designed new Corner Contour PLUS Shower Wall offers genuine solutions for more storage options and a contemporary slimmer look. There are five shelves providing plenty of storage, subtle hooks for hanging items, plus a convenient footrest. The shelves have built-in drainage and are easily cleaned in the dishwasher. Englefield's Corner Contour PLUS wall liner has IP protection via Patents 529079(NZ) & AU2004281617(AU) and Design Registrations 424475(NZ) & 201816970(AU).



- Wall Options**
- Shape:** 2 or 3 sided, reversible.
Size: 750 x 900mm corner
900 x 900mm corner
1000 x 1000mm corner
1200 x 900mm corner
750 x 900 x 750mm alcove
900 x 750 x 900mm alcove
900 x 900 x 900mm alcove
900 x 1200 x 900mm alcove
1000 x 1000 x 1000mm alcove
- Material/Finish**
- White 2mm thick Duracryl®sanitary grade acrylic.
1935mm height, compatible with all Englefield acrylic Quick Fit Trays.
Polycarbonate shelving.
- Included Components**
- One-piece moulded recessed acrylic wall liner.
5 clear shelves (3 standard, 1 towel bar, 1 footrest).
- Additional Components**
- Adhesive and silicone pack.
Premium coloured shelving with mirror (black or white).



Product Codes

2-Sided Wall	Wall Heights		Dimensions	
	1935	2010	A ^{+4/-2}	B ^{+4/-2}
900 x 750mm	706709A-0	-	884	734
900 x 900mm	706708A-0	701916A-0	884	884
1000 x 1000mm	706707A-0	701914A-0	984	984
1200 x 900mm	706706A-0	701912A-0	1184	884
1200 x 1000mm	32945A-0	32945A-2MH-0	1184	984

3-Sided Wall	Wall Heights		Dimensions		
	1935	2010	A ^{+4/-2}	B ^{+0/-2}	C ^{+4/-2}
750 x 900 x 750mm	706705A-0	-	739	860	739
900 x 750 x 900mm	706704A-0	-	885	742	885
900 x 900 x 900mm	706703A-0	701917A-0	884	860	884
900 x 1200 x 900mm	706701A-0	701913A-0	884	1160	884
1000 x 1000 x 1000mm	706702A-0	701915A-0	984	960	984
1000 x 1200 x 1000mm	32946A-0	32946A-2MH-0	984	1160	984