

## Kara Progressive Shower System With Spout Trim Kits Only





Versions:202401

### Drawing



#### Specifications

Watermark License

WM-060073

**Temperature Rating** 

Min 1°C-Max 75°C

Pressure Rating


Min 150kpa - Max 500kpa

#### Packaging Includes


- 1x Plate
- 1x Spout
- 1x Hand- Wheel
- 1x Diverter Knob
- 1x Hand Shower( Within Check- Valve)
- 1x 1m PVC Hose
- 1x Shower Bracket

#### Finish & SKU







- 1. Install tiles and drill holes with diameters of Ø20, Ø45, Ø30, Ø45.
- 2. Remove the pressure test plug.
- 3. Assemble the cutting gauge onto the mixer body, make it flush with the tile surface, and trim off any excess part after assembly.




 $5. A \mbox{djust}$  the distance between the Diverter knob and the tile surface to  $28-31 \mbox{mm}.$  as shown in the diagram.




- 8. Thread the water outlet adapter onto the in-wall body, and seal with Teflon tape. 9. Assemble the Backplate, washer, and shower bracket onto the main body, then secure with screws.
- $10. Attach \, the \, shower \, hose \, and \, hand \, shower, securing \, them \, in \, place.$




 $12. \, Assemble \, washer, and \, spout \, onto \, the \, mixer \, body, then \, secure \, with \, grub \, screws. \, Please \, Note: \, Waterproofing \, is \, required.$ 



4. Remove the cutting gauge and protective sleeves.




7. Apply waterproofing in the gap between the ceramic tile and the water outlet.



Follow step 11 to install the Hand-wheel and the Diverter Knob

11. Attach the wear-resistant O-ring, hand-wheel/ Diverter knob, grub screw, and silicone cap, securing them in place.



13. Installation is now complete. Test for leaks.

# Nero

